



Contents: 1 tripod base & 2 telescoping rods



Loosen knob at top of tripod base and spread the 3rd leg 45° to the rear.



The tripod is now freestanding. Tighten the knob.



Insert 2 rods into empty holes at top of gear mechanism on tripod.



Press button on front to spread the 2 legs that are attached to the gear mechanism.



Lay banner facedown on clean surface, then lay stand on facedown banner. Attach banner to the 2 hooks at the base of the legs of the tripod in the grommet holes.



Extend the 2 rods by turning nut on rods clockwise to loosen & then attach the hooks to remaining grommet holes on top.



Extend poles until banner becomes taut then tighten the nut on each rod by turning counter clockwise to secure.



Secure.

10



**YOUR EMPIRE-X BANNER STAND IS READY TO USE!**